INITIAL

Weather & Den. Alt. Weight & Balance Flight Plan - File Papers - A.R.O.W. Extinguisher/Emer. Ax Master - On Lights - Int / Ext Fuel Gauges - True Elec Master - Off

EXTERIOR SUMMARY

Fuel Quantity Fuel Quality Caps/Drains/Vents Engine / Oil Prop & Spinner Air Intakes Exhaust System Canopy Stall Indicator - Test Surfaces & Controls Pitot & Static Ports Gear / Tires / Brakes Antennas Ties/Chocks/Towbar Final Walk Around

INTERIOR

Passenger Brief ELT - Armed Hobbs / Tach Time Front Canopy - 1 or 2 Pedals - Adjust/Lock Fuel - Fullest Tank Circuit Breakers Alt. Air/Static - Close RR Door - Closed/Secure | Flt Instruments - Test

START

Canopy Lock Unblocked, Key Removed All Electrics - Off Prop - High RPM Mixture - Lean Prop - Clear Elec Master - On G1000 – Pwd-Ackd MFD - Eng-System MFD - Eng-Default Anti-Collision Lt - On Throttle -1/2" Open Fuel Pump - On Check Mixture – Rich 3-5 Secs. Then <u>Lean</u> **Brakes** Starter – Engage Mixture – Full Rich Oil Pressure/Voltage Annun & Eng Instr Fuel Pump - Off Pitot Heat - Test Avionics Master – On FMS Setup (I-F-R-P)* Autopilot - Test Lights - As Req

PRE-TAXI / TAXI

Mixture - As Req

Seat Belts / Harness Flaps – Test / T/O Fuel-Test Other Tank > 1 Min. @ 1500 RPM Heat / Vent / Defrost ATIS / AWOS Altmtrs-Set/Compare XPDR - Alt + SqwkADS-B - On Radio - Test Brakes - Test

RUN-UP

Brakes Trim - Takeoff Flight Controls Alt Air - Test / Close **Eng Instruments** PFD Annunciator Fuel - Reset / Set Fuel Pump - On Mixture - Best Power 2000 RPM Prop - Cycle x3 Mags-Test R-L-Both RPM Drop 175 RPM Max Difference 50 RPM

ALT Load Fuel/Oil Pressure Oil Temperature Idle - Check Closed **Throttle Friction**

PRE-TAKEOFF

Flaps - Takeoff Fuel Pump - On Canopy – Locked Door Warning Annun XPDR - Alt + Sqwk Heading Bug Strobes - On Time - Note Brakes - Release Landing Light - On FMS/GPS Flight Plan CDI Softkey-NAV Source

ABORT PLAN-READY!

TAKEOFF

CheckMate.

Full Throttle 2700 RPM Oil Pressure Rotate - * 59 Initial - 66 [67] Safe Alt - 73 [76] Flaps - Up

CLIMB

73 [76] 2400 RPM Instruments Trim – Adjust Mixture - Rich 5K, Hold EGT Constant Landing Light - Off Flight Plan - Open Fuel Pump - Off At Safe Altitude On At High Altitudes

CRUISE

Throttle Prop Mixture – As Req Instruments **Fuel Pump** On At High Altitude Fuel – Proper Tank Fuel Pump On While Switching Then Off After 10 Seconds

DESCENT

Throttle - MP As Req Fuel - Fullest Tank Fuel Pump - As Req Mixture - Adjust ATIS / AWOS Altimeter COM/NAV/FMS CHT - 150° - 475° Instruments

PRE-LANDING

Brakes - Pedal Test Seat Belts / Harness Landing Light - On Fuel Pump - On Mixture - Best Power Flaps – Takeoff

LANDING

Flaps – Landing Prop – High RPM * 71 [73]

G. U. M. P. F. S.

GO-AROUND

Throttle - Full Mixture Rich Flaps - Takeoff Airspeed - 66 [67]

AFTER LANDING

Flaps - Up Pitot Heat - Off Fuel Pump - Off Alternate Air - Off Lights - As Reg Mixture - As Req Trim - Takeoff XPDR - Alt + Sawk

SECURING

ELT - Verify Silent Avionics Master - Off Throttle - 1000 RPM Ignition Lights - Off Mixture - Full Lean Ignition - Off Elec Master - Off Hobbs / Tach Time Control Lock Chocks Tie Downs Canopy

Close Flight Plan

* Adjust Speed As Needed For Conditions. Check Your POH or Notes Cautions Plus Manufacturer For Revisions

When 2 Speeds Are Shown: 1st Speed Refers To MTOW: 2535 LBS ALL SPEEDS ARE KIAS 2nd Speed [#] Refers To MTOW: 2646 LBS

11161	15th difficults 1.00 t					_
Vr • Rotation - 59	Vs ₀ • Stall W/Landing Flaps – 4	19 [52] Va	a • Max Abrupt (1720 lbs) –	89 [94]	Vfe • Naps Landing –	91
Vx • Best Angle Climb-(1)66 [6	7] Vs • Stall w/o Flaps – 5	52 [53] Va	a • Max Abrupt (Full Gross) -	108 [111]	Vfe • Flaps Takeoff -	108
Vv - Best Rate Climb (2) 66 (50 [64] Vr	no • Max Structural Cruise –	129	X Wind • Max Demo'd	- 20
• • • • • • • • • • • • • • • • • • • •		/3 [76] Vr	ne • Never Exceed –	178		

	KNOTS	FLAPS	- NOTES -	
DEPARTURE Rotation * Best Angle Climb Best Rate Climb	59 ⁽¹⁾ 66 [67] ⁽²⁾ 66 [67]	Takeoff Takeoff Takeoff	** SEE POH & G1000 SUPPLEMENT FOR NOTES, CAUTIONS, WARNINGS (1) Vx w/Flaps T/O (2) Vy w/Flaps T/O (3) Hot Engine: Fuel Pump OFF, Throttle 1/2", Engage Starter. Short Field w/Obstacle: T/O Flaps.Lift Off * 52 53, Climb 58 59 Until Clear.	
CRUISE TAS-5,000' Economy Normal Maximum	118 127 136	Up Up Up	20.9" MP – 2200 RPM – 8.5 GPH – 55 % 23.1" MP – 2200 RPM – 9.5 GPH – 65 % 24.1" MP – 2400 RPM – 11.0 GPH – 75 %	
ARRIVAL Approach	85 71 [73]	Takeoff	1500 RPM (Initially)	* FMS Setup (I-F-R-P) Initialize Profile (Aux 4, MAP, MFD FPL, PFD FPL) Flight Plan Radios (COM, NAV, ADF, DME, CDI, BRG 1/2)

WARNING: Permission to use this CheckMate + is granted to the authorized purchaser only. No warranties, either express or implied, of any kind, are made hereunder, including, but not limited to any warranties for fitness for particular use. The information contained herein varies according to individual aircraft, model, and year of manufacturer and while we believe the information to be accurate, no representations are made as to the degree of accuracy of the information. This information constitutes only partial information necessary to properly operate an aircraft and is not to be used as a substitute for the use of other information sources routinely used in the operation of aircraft or the acquisition of requisite training to operate aircraft. Purchaser assumes all risk of use in using this product. Purchaser consents to and understands that CheckMate Aviation Inc., or any related entity, bears no liability for the use of this product.

Specs Are Approximate Because Of Environment & Plane

Model / Year Variables. Specs Are In: LBS, KIAS, Sea Level, Standard Day, Normal Category, Max Gross Wt , No Wind, "Best Power", Wheel Pants, New Engine. C ALL RIGHTS RESERVED 8.5

CheckMate Aviation Inc. 800 359 3741 1992-2022 NOS = 12 JEPP = 15

POWER LOSS IMMEDIATELY AFTER TAKEOFF / NO RESTART

MAINTAIN AIRCRAFT CONTROL

AIRSPEED - 73 [76] KIAS

FUEL SELECTOR – OFF

MIXTURE - FULL LEAN

FLAPS - FULL OR AS REQUIRED

BATT & IGNITION - OFF

PROTECT BODY

POWER LOSS IN FLIGHT

BEST GLIDE - 73 [76] KIAS

Flaps - Up, Max Gross Wt

ALTERNATE AIR - OPEN

NOTE WIND DIRECTION & VELOCITY

PICK LANDING SITE

FUEL SELECTOR - CHECK SELECTED TANK

FUEL PUMP - ON

IGNITION - VERIFY ON BOTH

THROTTLE - MAX POWER

PROP - HIGH RPM

ALTERNATE AIR - OPEN IGN CB-Pull If Installed To See If Rough Engine Clears

MIXTURE - BEST POWER

LOSS OF OIL PRESSURE - LAND ASAP

IF NO RESTART & TIME PERMITS

MAINTAIN BEST GLIDE

SOUAWK 7700

TWR, APP, Unicom, 121.5 **DECLARE EMERGENCY**

SEATBELTS / HARNESS

MIXTURE - FULL LEAN / IDLE CUTOFF

FUEL SELECTOR - OFF

Full Flaps When Field Assured FLAPS - AS NEEDED

BATT / ALT & IGNITION - OFF

PROTECT BODY

LAND SLIGHTLY TAIL LOW - 71 [73] KIAS Ldg. Flaps

IN FLIGHT SMOKE AND FIRE

Standby Horizon & Flood Lt. **EMERGENCY SWITCH - ON** ALT & BATT - OFF Unlatch Canopy To Ventilate

Open Emergency Window If Reg. CABIN HEAT - OFF

LAND AT NEAREST SUITABLE AIRFIELD

IF LIECTRONICS OR AVIONICS A MUST TO CONTINUE:

BATT-ON, ESS BUS-ON, Land @ Nearest Suitable Airfield

SMOKE OR FUMES PERSIST: ALT-ON, ESS BUS-OFF, BATT & ESS TIE CBs-PULL, Use Standby Instruments, Land ASAP Refer to ALT Failure

IN FLIGHT ENGINE FIRE

FUEL SELECTOR – OFF

Throttle - Full Open

CABIN HEAT - OFF

FUEL PUMP - OFF

INCREASE AIRSPEED TO EXTINGUISH - LAND ASAP

EMERGENCY LANDING - SEE: If No Restart & Time Permits

ENGINE FIRE DURING START

CONTINUE CRANKING ENGINE

Cabin Heat - Closed

IF START - RUN A FEW SECONDS - SHUTDOWN - INSPECT

IF NO START - FUEL SELECTOR - OFF

THROTTLE - FULL OPEN / CRANK ENGINE A FEW SECONDS

BATT & IGNITION - OFF

EVACUATE / FIRE EXTINGUISHER

ICING

ALTERNATE AIR - OPEN

PITOT HEAT - ON Air Distributor Lever-Up

Use Emerg. Window If Reg. CABIN HEAT & DEFROST – ON

STRONGLY CONSIDER 180° TURN / CLIMB OR DESCEND

AIR DISTRIBUTION LEVER - UP

INCREASE RPM SPEED

LAND FASTER AS REQUIRED

ELECTRICAL SYSTEM FAILURES

ALTERNATOR FAILURE: Indicated By Red ALT Message & 0 AMPS. Verify Cbs In, ALT Off Then On. IF DOESN'T COME BACK ON LINE -ESS BUS On, Turn Off Non-Essential Electric, Land Within 30 Mins. If PFD Attidude Info Is Lost Prior To Landing: Emerg. Switch On. (See Manual Supplement 3.7.2 To See What Items On ESS BUS)

PFD OR MFD FAILURE: Display Backup Button On Audio Panel-Push. AHRS FAILURE: Indicated By Removal Of Sky/Ground And A Red X & Yellow "AHRS FAILURE" On The PFD. Digital Heading Presentation Replaced With Yellow "HDG" And Compass Rose Digits Removed. Course Pointer Will Indicate Straight Up.

1) Use Standby Attitude Indicator, Magnetic Compass & Navigation Map.

2) Set Course Using Digital Window.

ADC FAILURE: 1) Use Standby Airspeed Indicator & Altimeter 2) Land As Soon As Practical At A Suitable Airport.

IN-FLIGHT EMERGENCY: DEPRESS & HOLD COM TRANSFER BUTTON FOR 2 SECS TO TUNE 121.5

UNICOM: 122.7 122.725 122.8 122.975 123.0 123.05

MULTICOM: 122.9 (CTAF) 122.75 (Air To Air)

FSS: 122.2

GROUND: 121.3 123.5 121.7 123.9

RADIO OUT: CHECK CIRCUIT BREAKERS & VOLUME RECYCLE ALTERNATOR SWITCH IF IFR & STILL OUT, SET XPDR TO 7600. (Suggested For VFR If In B, C, D Airspace.)

When 2 Speeds Are Shown: 1st Speed Refers To MTOW: 2535 LBS 2nd Speed [#] Refers To MTOW: 2646LBS

_		
Dia	mond Star DA40 G1000	Lycoming IO-360-M1A / 180 HP, Hartzell or MT Prop
••	Every Plane Has A	Different Empty Weight And Useful Load

* Empty Weight: LBS (Specific Plane Weight)

* Max. Useful Load: LBS (Including Fuel @ 6 lbs/gal)

Max. Baggage Areas: 66 LBS (Included In Useful Load) Max. T.O. Weight:

2535 LBS (Normal) 2161 LBS (Utility) 2646 LBS (IF OSB-40-057 CARRIED OUT) [INVOLVES LNDG GR STRUTS]

Fuel Type: 100LL (Blue) Usable Fuel: 40 Gallons

Oil Capacity: 8 Quarts (VFR Minimum-4) (IFR Minimum-6)

Electrical: 24-28 VOLT / 70 AMP

Tire Pressure: Nose-29 PSI / Main-36 PSI

EDITION #14, 1-12-2006, REV 8 12/1/10

C All Rights Reserved, CheckMate Aviation Inc. 1992-2022